

## Table of Contents

Get to Know Your Yealink Wireless Conference Phone .....	2
Home Screen.....	2
Calling Options.....	3
Dialing Phone Numbers or Extensions .....	3
Answer and End Calls .....	3
Hold Calls .....	3
Conference Calling .....	3
To Conduct a Conference Call.....	3
Muting a Call .....	3
Changing Volume .....	3
Transfer Calls.....	3
Perform Blind Transfer to an Extension or Other Number.....	3
Perform Attended Transfer to an Extension or Other Number.....	3
Do Not Disturb.....	4
Call History.....	4
Directory .....	4
Park .....	4
Unpark.....	4
Multicast Paging.....	4
Power.....	4



## Get to Know Your Yealink Wireless Conference Phone

### Home Screen



**Note:** The Yealink CP930W wireless conference phone works in conjunction with a DECT base station. The conference phone must remain within 150 feet of the base station to operate properly. For best results, it is recommended to position the base station in a central open area at least 6 feet above ground.

## Calling Options

### Dialing Phone Numbers or Extensions

- Place a call by manually entering a phone number or extension and then press *Send*
- Press *Cancel* to stop a call with dialing or ringing in progress
- **Local call** – dial the 7-digit local number
- **Long distance** – dial the 10-digit phone number (area code + local number). Dialing 1 before 10 digit number is optional
- **International** – dial 011 + country code + city code + number
- **Internal extension** – dial the extension or press *Directory / History*, and then press a desired entry. Select the phone number or extension to place call. If multiple numbers are available for the contact, select the desired number to place the call.

### Answer and End Calls

- To answer a call, press *Answer*
- To end the call, press *End Call*

### Hold Calls

- Place a call on hold by pressing *Hold*
- Press *Resume* to pick up the held call

### Conference Calling

#### To Conduct a Conference Call

1. Place call to or receive call from the first party
2. Press *Conf*.
3. Dial the number or extension and then press *Send*
4. Press *Conf* again to connect second party to the call
5. Repeat steps #2, #3 & #4 to add additional callers





**Note:** If outgoing call to other party is not answered (i.e., possibly going to voice mail, etc.), press *Cancel* followed by *Resume* to return back to the conference.

**Note:** If an incoming call is received while on an active call, just press *Join More*, then to add the caller or *Reject* to not add the caller





**Note:** that the conference phone supports up to 5 way calling (conference phone plus four other participants)

**Note:** To remove any participant that is on the conference call, press *Manage*, select the desired participant by using the up and down arrows and then press *Remove*.

### Muting a Call

- To mute an active call, press the *Mute* icon . The call is muted and the  icon is displayed on the LCD screen. The illuminated physical mute buttons change from green to red.
- To un-mute a call, press the *Mute* icon . The  disappears from the LCD screen. The illuminated physical mute buttons change from red to green.

### Changing Volume

- To change call volume, press  or  during a call
- To change the ringer volume, press  or  when the phone is idle or ringing

### Transfer Calls

#### Perform Blind Transfer to an Extension or Other Number

1. During an active call press *Transfer* and dial the extension/number
2. Press *B Trans*
3. The call drops off and has been transferred

#### Perform Attended Transfer to an Extension or Other Number

1. During an active call press *Transfer* and dial the extension/number
2. Press *Send*
3. The 3rd party phone begins ringing. Speak to other party and announce call
4. Press *Transfer* again to complete the transfer

## Do Not Disturb

- To enable do not disturb, press *DND*. A *DND* icon will appear at top of LCD display
- To disable *DND*, press *DND* again
- When *DND* is enabled, incoming calls will not ring the conference phone. Incoming calls will go directly to voicemail or receive a busy signal if voicemail is not enabled.

## Call History

- Press *History* to view call history, followed by *OK*. Use the up/down navigation arrows to view additional calls.

**Note:** A notification of any missed calls is displayed on the screen. Press *View* to see any missed calls.

## Directory

- Press *Directory* followed by *Network Directory*, then *All Contacts* to view phone numbers for your organization. Use the *Up/Down* navigation arrows to locate and highlight the desired contact. Press *Send* to call the desired contact.
- Press *End Call* to end a call that is actively being dialed / ringing

## Park (if enabled)

- While on an active call, press *Hold* followed by *New Call*. Enter #58 followed by *Send*. The call will be parked against an available extension such as 101, 102, etc. The system will automatically announce the park extension to the person that parked the call.

## Unpark (if enabled)

- Using the keypad, dial \*88 and enter the extension that the call was parked against. For example, park extensions are typically 101, 102, 103, etc. Press *Send* to retrieve the parked call.

## Multicast Paging (if enabled)

- Press *Menu, Features*, then use *Up/Down* navigation arrows to select *Paging List* followed by *OK*. Wait for the tone and begin speaking. The message is broadcast to all phones connected to LAN with paging enabled. The page is preceded by a beep tone. Press *End Call* to end the page.
- The conference phone will automatically receive broadcast pages from other phones on LAN that are setup with multicast paging

## Power

- To turn phone on, press and hold the red phone button or place conference phone in the charging cradle
- To turn phone off when phone is not in charging cradle, press and hold the red phone button, followed by *Yes*